



Adding User to User Authentication BH C550

Adding a user via the WebConnect

- 1. Open the WebConnect
 - There may be an icon on your desktop or a link in your browsers favourites.
 - If you do not have either of the above, open your web browser and type in the IP address of the copier into the address bar.
 - If you do not know the IP address, check with your system administrator
- 2. Login by selecting *Administrator* and clicking [Login]
 - NOTE: You may need to click [Logout] first to get this screen
- 3. Enter the administrator password (default is 12345678) and click [OK]
- 4. Click the [Security] tab
- 5. Under Security, click [User Registration] on the left hand side
- 6. To add a new user, click [New Registration]
 - To Delete a User, click [Delete]
 - To edit a user, click [Edit] and follow steps 7-12










Adding a user via the copiers control panel

- 1. Press [Utility/Counter]
- 2. Touch [Administrator Settings]
- 3. Enter the administrator password, and touch [OK]
 - a. The default admin password is 12345678
- 4. Touch [User Authentication/Account Track]
- 5. Touch [User Authentication Settings]
- 6. Touch [User Registration]
- 7. To register a new user, touch an empty box
 - a. To delete a user, touch the username and then touch [Delete]
 - b. To edit a user, touch the username then follow steps 8-15
- 8. Touch [Edit]
- 9. Enter the desired [Username]
- 10. Enter the desired [Password]
- 11. Enter an [Email Address] (optional)
- 12. Touch [Output Permission]
 - a. Enter the desired restrictions
- 13. Touch [Max. Allowance Set]
 - a. Enter the desired restrictions
- 14. Touch [Function Permission]
 - a. Enter the desired restrictions
- 15. Touch [OK]








Setting Up The Print Driver

Now that the user has been entered, they need to have their print driver set up so that they can print.

- 1. Open Printers & Faxes (Windows XP) or Devices and Printers (Windows 7/Vista)
- 2. Right click the printer and select [Properties] (Windows XP) or [Printer Properties] (Windows 7/Vista)
- 3. In the properties box that pops up, click the [General Tab]
- 4. Click [Preferences...]
- 5. Click the [Basic] tab
- 6. Click [Authentication/Account Track]
- 7. Select [Recipient User]
- 8. Enter the *Username* and *Password*
- 9. Click [OK] 3 times






Printing Colour with User Authentication

Since the driver is already set up with the username and password, printing in colour is easy.

- 1. In your application, click [File] -> [Print]
- 2. Make sure your printer is selected in the *Name* dropdown box
- 3. Click [Properties...] (Note: In some programs, the button may be "Preferences")
- 4. In the Properties box that opens, click the [Quality] tab
- 5. Select [Full Color]
- 6. Click [OK]
- 7. Click [OK] to print your document





Copying colour with User Authentication

- 1. If you do not see the *Login* screen, touch the [Access] button to the left of the number pad (beside the 1)
- 2. In the login screen, touch [User Name]
 - Using the touch screen keypad, enter the username, and touch [OK]
- 3. Touch [Password]
 - Using the number pad or touch screen keypad, enter the password and touch [OK]
- 4. Touch [Login]
- 5. Touch the [Color] box
- 6. Select [Auto Color] and touch [OK]
- 7. Make your other desired changes
- 8. Press the [Start] key

